BMW Motorcycles Maintenance Schedule for K-Models



		BMW Inspection 600 miles	BMW Service 4-6,000 miles	ion	e	
Customer Name	Repair Order Number / Date			BMW Inspection 8-12,000 miles	BMW Annual Service	
Vehicle Identification Number (VIN)	Mileage In	BMW 600 I	BMW 4-6,0	BMV 8-12,	BMW Annuá	
Check Vehicle History for any outstanding recalls.						
Read MOTRONIC fault memory with BMWMoDiTeC. (motorcycles with 4-valve engines only)						
Check brake pads and discs for wear, renew as necessary*						
Check front and rear brake fluid levels.						
Check brake system with regard to function, and leaks. Repair as required *						
Change brake fluid once a year with	n DOT 4 fluid.					
Check ABS sensors/pulse wheels for correct gap/contamination Adjust and clean as required *						
Change engine oil when at operating temperature, renew oil filter. (for short distance driving or when outside temperature is below 32 F, every 3 months or 1800 miles.)						
Change transmission oil when at operating temperature.						
Change oil in rear drive and telescopic fork when at operating temperature.						
Clean inductive speed sensor at rear drive.						
Check/adjust valve clearances. (every 16,000 mi. for 4 valve engines)		□ ¹⁾				
Renew the lining of the chain tensioning rail & chain guide every 36,000 miles.*						
Replace spark plugs						
Check hose clamps on fuel & cooling system for leaks; retighten if necessary. Check coolant level & concentration, correct if necessary.						
Renew coolant every 2 years.*						
Renew fuel filter every 24,000 miles*; if fuel quality is poor every 12,000 miles.						
Drain and clean fuel tank every 2 years*						
Renew intake air filter (if riding in dirty/dusty conditions renew every 6,000 miles/check more frequently)						
Lubricate applicable splines every year* (input shaft, paralever, driveshaft) Motorcycles produced from 1990 onward, lubricate every 40,000 miles.)						
Check play in steering, wheel and swi and swing arm bearings every 25,000 miles*)	ngarm bearings, renew if necessary. (replace wheel					
Check clutch clearance, adjust if nece ples.	essary. Grease upper & lower clutch cable nip-					
Check throttle cable & choke cable free (in severe operating conditions, grease the thrott						
Check battery acid level, top up with w	water if necessary. Clean & grease battery posts.					

* invoiced as a seperate item 1) K75 models only

 \mathbb{Q} Continue on page 2 \mathbb{Q}

BMW Motorcycles Maintenance Schedule for K-Models K75 K100 K1100 K1	BMW Inspection 600 miles	BMW Service 6,000 miles	BMW Inspection 12,000 miles	BMW Annual Service
Check operation of sidestand switch (angle); or retracting sidestand linkage (K75's)				
Apply silicone spray to guide rods of adjustable windshield (only K1100LT, K75RT)				
Check torque at the bolts and nuts: • engine to frame • suspension strut mounts • side & center stand pivot • rear wheel studs • front axle studs, clamp bolts, brake caliper mounting bolts				
Adjust tire pressure to specification: Frontpsi. Rearpsi.				
 Final Inspection with Safety / Operating check: Condition of tires and wheels Lights, horn, and signal system Telltale and warning lights Clutch and gear shift Steering, hand & footbrake, ABS Instruments (including optional accessories, radio, etc.) Check & adjust engine idle speed Check and adjust CO content of exhuast (models with closed loop catclyic con verters Test ride, visual quality check 				
* invoiced as a separate item 1) K75 models only Maintenance Complete, Sign and Record Milea	ige Belo	w Ū	Page	e 2 of 2

Technician Signature

Date

Mileage Out